# HP Laserjet E50145

## IP Address | Configuration Report Page | Basic Driver

IP Address

From the main screen, select the 'information' icon at the top

On the next screen, tap the Ethernet option with the networking icon next to it


The IP Address should appear on the 'Ethernet Summary' screen.

Print Configuration Report

From the main screen, swipe to the left until you see the 'Reports' option (in the 3rd section).

On 'Reports,' select 'Configuration/StatusPages.'

Select 'Configuration Page' and tap the Print Icon, then you will see the 'Preparing Job' prompt at the top

Locate the IPv4 Address on the page
10.102.34.567

Driver (PCL 5)   https://drive.google.com/drive/folders/1BwUkfVD3HLiTWTZpvuzUKrXQla0bKFHD